

B120/5 Humidifier Maintenance Program

| <i>Time Interval</i> | <i>Items to check</i> |
|-------------------------------|--|
| Every time the unit is filled | <ul style="list-style-type: none"> • Add Waterfresh if required |
| Every Day | <ul style="list-style-type: none"> • Visual Check of humidifier – ensure that the machine is ‘behaving’ as it should ie water level sufficient, water quality, no leaks, fan working. |
| Every two to three months | <ul style="list-style-type: none"> • Check Filter condition (replace if required) • Empty all water in the tank • Check Motor with Fan and Pump are operating well • Check Float Indicator is working • Quickly wipe clean everything |
| Six / twelve month service | <ul style="list-style-type: none"> • Replace Filter • Clean internal components including:- <ul style="list-style-type: none"> ○ Float Indicator ○ Water Distribution Channel ○ Pump / Fan ○ Reservoir ○ Water Pipes • ensure the body of the machine is free from lime deposits by wiping down (externally and internally) |

Replace the Evaporation Disk as and when required (maximum one year) and always use mild cleansers and rinse fully before using again. Customers in hard water areas will find that filters need to be replaced more often and that greater cleaning is required. Never wash filters.

Always unplug the humidifier before starting any maintenance